



# Food Slicer Care and Use

Model: #34055

## USE AND ASSEMBLY:



Scraper



Cover

Base

Blades



Set base with blades facing up on the counter



Place food on blades




Place cover over food and push down firmly to slice



Only use scraper to clean grid inside cover

## RECOMMENDED FOODS:

*Do not use with: apples, hard root vegetables like potatoes; carrots; radishes. Make sure to remove pits from pitted fruits before slicing*



*For best results, do not overfill.*